SmartDispenser® MDAV LOW TORQUE BENCHTOP CA SYSTEM




AirFree® Technology & Cyanoacrylate

Traditional air pressure systems inject moisture filled air into the syringe reservoir activating the cyanoacrylate (CA) cure cycle. AirFree® technology eliminates moisture filled air from the dispensing process protecting the CA formulation. As a secondary safeguard Genius® CA components are made from proprietary plastics that inhibit CA bonding between components.

Total Cost of Ownership

AirFree® Technology Adds Profits When Replacing Air Driven Systems



Fishman Corporation 192 South Street, Hopkinton, MA 01748, United States US & Canada: 800-433-2115 | United Kingdom: 1905 456008 | Europe: +441905 456008 Worldwide: 1-508-435-2115 | www.fishmancorp.com



SmartDispenser® MDAV-LT BENCHTOP CA SYSTEM

MDAV-LT-CA Medium Dot Any Viscosity

BARREL SIZE	зсс	5CC	10CC	
MIN.VOL. (CC)	.00045	.00079	.00131	
MAX. VOL. (CC)	3.0	5.0	10.0	
MIN. RATE (CC/SEC)	.011	.020	.033	
MAX. RATE (CC/SEC)	.267	.477	.783	
MAX. BACKOFF (STEPS)	500	500	500	
MAX. DELAY (SEC)	9.99	9.99	9.99	



The SmartDispenser® MDAV-LT-CA (3-10cc) comes with 3-10cc Dispense Gun and 3, 5, 10cc Retaining Rings.

MIN.VOL. (CC)	.00257
MAX. VOL. (CC)	30.0
MIN. RATE (CC/SEC)	.064
MAX. RATE (CC/SEC)	1.543
MAX. BACKOFF (STEPS)	500
MAX. DELAY (SEC)	9.99



The SmartDispenser® MDAV-LT-CA (30cc) comes with 30cc Dispense Gun and 30cc Retaining Rings.


Genius® Cyanoacrylate Dispensing Components

Genius[®] CA dispensing components are designed from a proprietary plastic that prevents the CA from bonding the syringe piston to the syringe barrel and the syringe tip cap to the syringe luer.

Genius[®] CA FreeFlow[™] Tips and Teflon[®] Tips

Genius[®] FreeFlow[™] CA Tips and Teflon[®]* Tips both prevent CA from clogging the tip during the fluid dispensing process.

*Teflon is a registered trademark of the Dupont Corporation.







SMARTDISPENSER[®] MDAV-LT-CA 3-30CC DISPENSE STARTER KIT CONTENTS

- Foot Pedal
- Keyboard
- Mouse
- Earphone
- Video Camera
- Cisco Wireless Connectivity Device
- Needle Kit
- Manuals
- Power Supply Connection
- Universal Power Supply













SmartDispenser[®] MDAV-LT BENCHTOP CA SYSTEM



SPECIFICATIONS Usage: Indoor use Up to 2000m Altitude: Temperature: 0° to 40° C Maximum Relative: 80% for temperatures up to 31° C decreasing linearly to 50% relative humidity Humidity: at 40° C Mains Supply Voltage Fluctuations: Not to exceed ±10% Installation Overvoltage: Category II Pollution: Degree 2, Class 1 Input Voltage: 100-240 VAC 47-63Hz Max Inrush Current: 3.2A-1.8A Output Voltage: 5.0VDC Output Power: 4.6W Fuse Rating: 1.0A/250 VAC Initiate Circuit: Foot Pedal (dry contact) finger switch Drive Motor: MDAV-LT-CA 3.75 Degree 96 Steps/Rev Axial Movement: MDAV-LT-CA .024 Axial Pitch .00025"/Step **Control Circuitry:** CMOS microprocessor Interface: Touch Screen or Keyboard/Mouse **Minimum Dispense** Volume: 0.00045ml

CONTROL UNIT

Weight:

5.6 x 9.9 x 6.3in (14.23 x 25.15 x 16cm) 4.7lbs (2.13 kg)

GUN Length:

7in (17.8cm) Weight: 6oz (170.1 gr) 3 feet (91.5cm) Cable Length:

What makes the SmartDispenser[®] so smart? The combination of 3 powerful platforms.

AIR-FREE MANUFACTURING

- One program worldwide
- Closed-loop feedback
- 6-10X more repeatable than pneumatics
- Volume base numeric dispensing
- · Positive displacement via stepper motor
- Firmware proven for over a decade
- Eliminates expensive air compressor
- Designed to integrate into automation systems using PLCs

- WINDOWS 7 NETWORKING
- SD Device to MES System Networking
- Remote programming and lock out
- Real time production data
- Live video feed
- Auto e-mail of unauthorized program changes
- On screen work instruction (audio option)
- Connectivity between SmartDispensers[®] Desktop, Laptop and Smartphone.
- Video/Audio training and tutorials

SMARTPHONE FUNCTIONALITY

- Touch screen
- Finger gesturing controls
- MES Networking Apps
- Custom Manufacturing Apps



Fishman Corporation 192 South Street, Hopkinton, MA 01748, United States US & Canada: 800-433-2115 | United Kingdom: 1905 456008 | Europe: +441905 456008 Worldwide: 1-508-435-2115 | www.fishmancorp.com